

# Guide to Fitting Track Adapters in CRM pedals

---



1. Push the roll pin into lever until 3mm exposed on the inner side.



2. Assemble spring on locking pin shaft and insert locking pin in pedal with the chamber facing forward.



3. Hold the pedal in one hand with the locking pin pushed into the pedal. Slide lever/roll pin assembly over the end of the pin and insert the roll pin into the hole in the locking pin.



4. Use grips as shown to push home the roll pin. Use a screwdriver blade to adjust the pin to be positioned symmetrically and ensure the lever works smoothly.